

◆ Sensing tool for turning

Model number	Applicable insert
DCLNR/L2525M12	CN□□1204
DDJNR/L2525M15	DN□□1504
DDHNL2525M15	DN□□1504
DVJNR/L2525M16	VN□□1604
DVQNR/L2525M16	VN□□1604
MTJNR2525M16	TN□□1604
DTGNR/L2525M16	TN□□1604
DWLNR/L2525M08	WN□□0804
DDNNN2525M15	DN□□1504
SDJCR2525M11	DC□□11T3
SVLCR2525M11	VC□□1103
SCLCR2525M09	CC□□09T3
PRGCR2525M12	RCM□12